

# Buildex®







**NEW**

# POLY ZIPS®

Fixing polycarbonate roofing to timber & steel battens

## *Predrills its own expansion hole*

### Save up to 50% installation time!

-  **Suitable for profile heights 16mm to 29mm**
-  **New ZIPS® drill point for fast and easy fastening into both timber and metal battens up to 1.6mm thick**
-  **Uniquely designed 26mm EPDM washer with inner sealing ring to prevent water entry**
-  **Climaseal® 3 coated that meets real world testing to AS3566 Class 3**
-  **Patent pending wing design drills an oversized hole into the polycarbonate material, eliminates sheet buckling and water entry due to expansion in high temperatures**
-  **Backed by the Buildex Warranty, to match the life of the sheeting**

Distributed By:

# AMPELITE

Ampelite Australia Pty. Ltd.  
Cnr Kitchen & Zenith Roads  
Dandenong Vic 3175

www.ampelite.com.au  
**PH: 1800 800 094**



Gauge	TPI	Length
M6.5 (14g)	14	50mm
Hex Washer Face with 26mm EPDM Seal		
Pack Type	QTY	Part No.
Trade pack	50	1-030-7316-4
Bucket	250	1-030-0316-7CSBT
Trade Box	500	6-030-0316-6CS



**Buildex®**

# POLY ZIPS®

Fixing polycarbonate roofing to timber & steel battens

## Installation Instructions



### Step 1:

Insert PolyZips® into 5/16 socket and carefully position screw in centre of sheet crest to prevent any skidding or scratching.



### Step 2:

Using a variable speed screw gun, start drilling slowly keeping screw straight to give you the correct oversized hole in your polycarbonate material.



### Step 3:

Keep driving screw until it engages into the batten and EPDM washer sits securely. Do not over tighten screw, as it may cause failure.

*PolyZIPS® is suitable for fixing into both timber and metal battens up to 1.6mm thick. Some hardwoods may require pre-drilling.*

*Always check with material supplier recommendations for number of fasteners and spacing's required.*



**No predrilling required**

**WARNING:**  
Always wear safety glasses installing this product.



Distributed By:

**AMPELITE**

Ampelite Australia Pty. Ltd.  
Cnr Kitchen & Zenith Roads  
Dandenong Vic 3175  
[www.ampelite.com.au](http://www.ampelite.com.au)

**Victoria & Tasmania**

PO Box 4263  
Dandenong South  
VIC 3164  
Tel: (03) 9794 0977

**New South Wales**

PO Box 4186  
Tregear NSW 2770  
Tel: (02) 9625 7200

**Queensland**

21-23 Cronulla Court  
Slacks Creek,  
QLD 4127  
Tel: (07) 3808 6211

**South Australia**

3 E.W. Pitts Avenue  
Cavan SA 5094  
Tel: (08) 8260 7391

**Western Australia**

91 Excellence Drive  
Wangara WA 6065  
Tel: (08) 9302 6833

PolyZips, Teks, Weatherlok and Climaseal are registered Buildex® Trademarks.

Whilst every care was taken in preparation of this guide, Buildex® accepts no responsibility for the accuracy of the information supplied. Copyright © 2007.

The contents of this brochure are the exclusive copyright of Buildex® and may not be reproduced without written permission.